


Digital Force Gauge

Models DFS — 0.5, 1, 2, 5, 10, 20, 50, 100
DFS — 0.5R, 1R, 2R, 5R, 10R, 20R, 50R, 100R

Instruction Manual

Contents

Safety Precautions	2
Factory Settings	2
How to Change Units	3
How to Change Measuring Modes	3
Memory Modes	4
Single (on-demand) Mode	4
Statistics	4
Continuous Memory Mode	5
Standard Memory Mode	5
Memory Back-up	5
Comparator	5
How to Set Limits (HI/LO)	6
Parameter Setting	6
How to Select Parameters	7
Measuring Time & Peak Fast Mode	7
Setting Measuring Time & Peak Fast Mode	8
Auto-Power-Off	8
Setting of Initial Conditions	9
Output Selection	9
RS232C Output	10
Selecting Memory Mode	11
Error Codes	11
Low Battery Indication	11
External Control Input (TARE, HOLD)	12
External Input Selection	13
Outputs(Analog, Comparator, Digimatic, RS232C)	14, 15
Memory Data Output thru RS232C	16
Commands (External Control Command thru RS232C)	17
Overload Output & Flow Control	18
Calibration	19
Warranty	19
Specifications	20



Safety Precautions

1. Do not use any attachment that appears to be damaged.
2. Attachment must be properly installed. Hand tighten it. Do not use wrenches or any other tools.
3. Do not exceed attachment capacity.
4. When installing gauge on a stand make sure to use all necessary screws to secure unit.
5. Use eye protection devices when testing materials that may shatter.


Caution

1. Do not use or store unit in extreme temperatures.
Note: Operating temperature is 0-45°C.
2. Do not use or store unit in oily, dusty or water splashing areas.
3. If display shows EEEE stop test immediately and release load. Over-load condition may damage the load cell.
4. Do not apply force at an angle and avoid twisting the shaft.
5. If gauge is not going to be used for a while, remove batteries to avoid corrosion of battery terminals.
6. Use AC adapter that comes with the unit only. Any other adapter will damage circuitry.
7. Do not use any chemicals to clean outside case (including gasoline, alcohol e.t.c). Just use ordinary soapy damp cloth.
8. Do not attempt to disassemble gauge. The warranty will be voided.

Before Using

All DFS models come from the factory with the batteries not installed. Before attempting to use the gauge install the four AA batteries (provided) observing Figs. 1, 2 and 3 below. Remove battery plate with a coin or appropriate screw driver. Install 4-AA batteries as shown in Fig. 2 observing proper polarity. Make sure lip engages properly before tightening the battery plate screw.

Note: When the AC adapter is used, the batteries act as a memory back up system only.



Factory Settings

Each force Gauge comes from the factory with the settings shown in the table 1 below

UNIT	lb. or oz. (Depending on capacity)		
MEASURING MODE	Average		
UPDATE TIME	0.125 seconds		
AUTO POWER OFF	3 minutes		
MEMORY MODE	on demand mode (single data input)		
OUTPUT	RS232 (EIA)	Baud Rate: Data Length: Stop Bit: Data End Code: Software Flow Control:	4800 bps 8 bits 2 bits None Disabled
INPUT	Tare Function		

Table 1





Fig. 1

Push Button Functions



Ready to Measure

First press the ON switch to turn power ON. The display will show momentarily all the indicators shown in Fig.1 and then settle at lb (oz) and some arbitrary number with (usually but not necessarily all zeros).

Assuming that the proper attachment is installed and the unit is positioned as desired, press the ZERO and ON switches simultaneously. The display should show all zeros, which means that the gauge is "TARED".

The gauge is now ready to measure force according to the factory settings shown in Table 1.


After measurements are finished, press the OFF switch to turn unit off.

Note: The gauge will power off automatically in 3 minutes if the OFF switch is not pressed. If the AC adapter is in use, the AUTO-POWER-OFF function is inoperative.

How to Change Units

After the power is turned ON and gauge is "TARED", by pressing the UNIT switch the instrument will change from lb(oz) to kg(g) to N and the cycle is repeated.

Caution: The gauge will default to lb (oz) (initial setting) after power OFF regardless of what unit was previously selected. To avoid above situation, see page 7.




Change of Measuring Mode

As was mentioned in previous pages the gauge is set from the factory in the average mode. The sampling rates for the average mode are 0.125, 0.25, 1 and 2 seconds (selectable). In the PEAK mode if the sampling rate is set for 1/1000 sec., the actual peak force is captured. If another sampling rate is chosen the maximum average force is captured. To change from average to peak mode press the PEAK switch once. The display will show a negative sign in front of the digits. This means that the gauge is ready to measure tension. If the PEAK switch is pressed one more time the negative sign will disappear and the gauge is ready to measure compression. One more press of the PEAK switch will bring the unit back to average mode.

The gauge is able to measure average, peak tension, and peak compression in one operation. When in the average mode, push on the shaft for a period of time and then pull the shaft and release. When you press the PEAK switch the peak tension appears on the display. One more push of the peak switch and the display will show the peak compression. To cancel the peak value from the memory press the RESET switch.

The gauge is set to go to the average mode when the power is turned on. To change this condition (go to peak on POWER ON) see page 7.



Memory Modes

The memory of the DFS series operates in three distinct modes:


1. On-demand memory mode (single)
2. Continuous memory mode
3. Standard memory mode

ON-DEMAND MEMORY MODE (SINGLE)

The unit comes from the factory set on the on-demand mode. One hundred data can be stored in memory by pressing the MEMO SET switch. If more than one hundred data are forced into memory, the word FULL will appear on the display. To recall the data in the memory press the RECALL switch. The last data and memory position show up on the display first. Any subsequent switch pressing will decrement the data and memory position

By pressing the \triangleright key, the last data in memory will be erased. If unit is allowed to go OFF and then ON again, the last data cannot be erased by pressing the \triangleright key. To clear the memory press RESET and ON switch at the same time.

The display will show $\square \square \square \square$ momentarily and then go to all zeros. If RECALL is pressed, the display will show $\square \square \square \square$ momentarily.




STATISTICS

After the desired data has been stored in memory, set the gauge in the RECALL mode and press the PEAK mode switch. The last memory position will be displayed and also the data in that position.

Subsequent manipulations of the peak switch will bring up maximum, minimum, average data, and standard deviation. See diagram below:

After standard deviation, by pressing peak again the unit goes to maximum. To escape from statistics press the RECALL switch. To escape from RECALL press the RESET(ESC) switch.



TO CLEAR MEMORY

To clear memory from all data, press RECALL switch first and then press simultaneously the ON and RESET switches.


The display will show $\square \square \square \square$ momentarily and everything will default to MEASURE (ready) state.

Note: If the “UNIT” switch is pressed after a set of data has entered the memory and new data is attempted to enter the memory in different “units”, the display will show $\square \square \square \square$ which means that this action should be avoided. You cannot change units during the process of entering data into memory.

CONTINUOUS MEMORY MODE

If the continuous memory mode must be used, do the following to change from the ON-DEMAND mode to continuous mode.

1. Press ON & PEAK at the same time.
Display will show $\cdot d5P\bar{t}$.
2. Press PEAK. Display will show $\cdot PF5\bar{t}$.
3. Press PEAK 5 times. Display will show $\cdot L\bar{a}\bar{t}$.
4. Press MEMO SET. Display will show $S, n\bar{t}$.
5. Press PEAK. Display will show $n\bar{o}nE$.
6. Press PEAK. Display will show $\bar{c}o\bar{n}t$.
7. Press MEMO SET. Display will show $\cdot d5P\bar{t}$.
8. Press RESET. Now you are in the continuous memory mode.



You can enter 100 measurements at once in this mode. While force is applied on the shaft, press MEMO SET.

The display will be changing according to force applied and the letter M will be blinking on top of the numbers. When 100 measurements have entered the memory, the M letter will disappear momentarily and the word FULL will appear on the display momentarily and the letter M will reappear solid. You can recall each measurement by pressing the RECALL switch. To clear the memory press RECALL, then RESET and ON at the same time and the cycle can be repeated.

Statistics can be performed in this mode as previously described. If the $\cdot PF5\bar{t}$ is OFF, statistics can be performed as described in previous pages. If the $\cdot PF5\bar{t}$ is ON, then the PEAK force will show up between MIN and A (minimum and average).

STANDARD MEMORY MODE

Follow the same procedure as the one described above to select the standard memory mode. The display will show nonE. Proceed with steps 7 and 8 described above to stay in the standard mode. In this mode the maximum and minimum force (tension and compression) and last measurement are

stored in memory in a selected period of time and can be recalled later. If the selected period falls between a continuous compression and tension measurement, then the maximum compression and tension force will be stored and the minimum will be zero for both.

MEMORY BACK UP

When power is off, memory back up is provided by the batteries. If batteries are getting low, before a new set is installed it is important to use the AC adapter and leave

power ON before removing old batteries otherwise data in memory will be lost. When the AC adapter is used the batteries are used as a memory back up system only.

COMPARATOR

Two set points are available HI and LO.

Note: When the Digimatic output is selected, the comparator output is not available. HI point is defined as follows:

HI < DATA (display)


OK or GO is defined as follows:

LO ≤ DATA ≤ HI

LO is defined as follows:


LO > DATA (display)

When setting the HI and LO limits, see adjacent diagrams.



How To Select Parameters

1. Press ON and PEAK switches simultaneously. The gauge will display $\overset{\wedge}{dSPt}$.
2. Press PEAK. The display will show $\overset{\wedge}{PFSt}$. By pressing the PEAK switch the display will show the following sequence:



3. If you choose $\overset{\wedge}{LoG}$, press the MEMO SET switch. The action will get you in the memory field (single, none or continuous).

Note: If you press the RESET switch while you are in the memory field, the unit will default to step 2 $\overset{\wedge}{LoG}$.

4. Press PEAK to display and choose any of the three modes.



5. Press MEMO SET to enter your selection, like $\overset{\wedge}{Cont}$ → $\overset{\wedge}{dSPt}$. After selection is made press RESET.


Measuring Time and Peak Fast Mode

Measuring time: Select one of the four time periods 0.125, 0.25, 1, or 2 seconds. When the peak fast mode is OFF, the gauge will average the data for the selected period at the 1000/sec. rate. When the peak fast mode is ON, the gauge will capture the maximum peak value from all data for the selected time period at the 1000/sec. rate.

The table at right shows the response time of the various models. Due to mechanical limitations the table shows the 90% response time (see graph 1).

MODEL	RESPONSE TIME
DFS-0.5, 1	35 ms
DFS-2	12 ms
DFS-5, 10	8 ms
DFS-20, 50, 100	6 ms


Response times are shown with small attachments. If heavier attachments are used the response time will be slower.



Setting Measuring Time and Peak Fast Mode

See flow chart below. Press ON and PEAK switches simultaneously. The display will show dSPt

Set measuring time and PEAK fast mode as the diagram below indicates.




Auto - Power - Off

This option can be selected. If the auto-power-off option is selected, the power will be turned off automatically after 3 minutes if no switches are activated during that time and if no force change occurs during the 3 minute period. Force change must be less than 0.1% of gauge's capacity to be defined as no change.

The auto-power-off will not work if

- not selected
- unit is in the continuous memory mode and data are entering memory
- AC adapter is in use
- Unit is in calibration mode

Here is how to set up or cancel the auto-power-off option.



Setting of Initial Conditions


The gauge comes from the factory with the “unit” set in lbs and the “measuring mode” in average. The “unit” condition can be changed to N or Kgs by depressing the “unit” push button. If a unit is selected other than lbs., when the power is turned off and on again the gauge defaults back to initial

setting which is lbs.

The same holds true if the gauge is set at the auto-power-off condition.

To opt out of this condition follow the diagram below.

See page 7 to get to `^ i n i t` and follow diagram as shown.




Output Selection

The operator has the option in selecting:

- a) RS232C
- b) Digimatic
- c) None


See page 7 and set the display on the `^ o u t`

See flow chart below to select any of the outputs above.



RS232C output


If the RS232C output is selected, more parameters must be chosen. See flow chart below:



When you have entered the RS232C output field and you don't want to change the factory settings, just press RESET and you will exit this field.

Choosing Memory Mode

See page 7 to get to \wedge LoG . Choose one of the memory modes according to the diagram shown below:



Error Codes

If any of the error codes show up in the display, turn power off and then on. If the error code remains, see table below:

DISPLAY	CONDITION	ACTION
Er01	E PROM ² reading error	Press RESET. Unit should go to factory settings
Er02	Temperature compensation error	Bad temperature compensating ckt. Send unit for repair. Unit may be used if temperature is not a problem. Press RESET.
Er03	Calibration error	Unit needs repair and recalibration
Er04	D/A converter error	Analog output will not tare. When tare is pressed the voltage will not go to zero. All else is OK. Repair is needed. Press RESET.
Er06	RS232C communications error	Check connections and all RS232C parameters
Er07	Memory unit error	This occurs if "units" are changed during memory data entering. Some data in lbs, then some in kgs, etc. Change units or clear memory
EEEE	Overload condition or load cell damaged	<ul style="list-style-type: none"> • Use proper load • Repair unit by changing load cell



Low Battery Indication

When the letter B shows on the display, it means that the batteries have to be changed. **Note:** Memory back up is accomplished thru the batteries. Before changing batteries, in order not to lose data in memory, plug in AC adapter and turn gauge on.

External Control Input

TARE and data display HOLD can be externally controlled. The Digimatic output shares the same wires as the external control input. Make sure to use the RS232C output or no

output when the external control input function is used. The external input cable looks like the one below:



External TARE


To tare, short pins 5 and 10 for at least 25 ms.

External HOLD

Choose edge or level trigger and also OPEN or CLOSED condition.


1. Level trigger: OPEN

Display holds present value when switch opens.




2. Level trigger: CLOSED

Display holds present value when switch closes.




3. Edge trigger: OPEN

Display holds present value after switch opens until it is reset.



4. Edge trigger: CLOSED


Display holds present value after switch closes until it is reset.




HOLD cannot be released from an external source in the edge trigger mode. To release it press RESET. Level mode can be released externally.

External Input Selection

From page 7 go to Et






When in HOLD mode, select trigger mode as follows:



Output

There are four outputs available:

1. RS232C
2. Digimatic
3. Analog
4. Comparator



*Digimatic, External input and Comparator output share wires.

I. Analog Output

The analog output is not derived from the CPU but is generated from the load cell and amplifier. It is very linear and has a high response time. When in TARE mode, the analog output goes to zero volts.

Specifications

Voltage: -1VDC ~ 0 ~ +1VDC


Load Impedance: 2K or higher

Response Time: 35mS (DFS-0.5/1)

12mS (DFS-2)


8mS (DFS-5/10)

6mS (DFS-20/50/100)




Comparator Output

The comparator output shares wires with Digimatic and External input, therefore when Digimatic is selected, the comparator output is not available.




OC output
28 VDC, 7mA (max)




Digimatic Output

Connect cable between gauge and Mitutoyo Model DP-1HS printer. Select Digimatic output according to previous instructions described on page 9. Press RECALL to display DATA in memory. Then press MEMO key. All data in memory will be outputted into the printer. During the transfer of DATA from unit to printer the doUt word on the display will be blinking. When all data have been transferred, the unit returns to measuring mode and the display stops blinking.



If the printer DATA key is pressed, only one measurement at a time is transferred into the printer. STATISTICS from the gauge will not be outputted because the printer has its own capability of performing all the statistical functions.



```

          98 10.006  M
          99 10.001  M
          100 10.000  M


PART NO.
.....
DATE/TIME
.....
NAME
.....

*RESULT*
N          100
MAX 10.053  M
MIN  9.949  M
R    0.104  M
      0.01921 M
      0.01931 M
      10.00262 M
    
```

RS232 Communications

All communications between the gauge and the PC are possible with only one exception, the PC cannot turn the gauge ON and OFF.

BAUD RATE	1200, 2400, 4800, 9600
DATA	8 bits
STOP BITS	1, 2
PARITY	none, even, odd
DATA END CODE	CR, CR + LF
SOFTWARE FLOW CONTROL	(X ON, XOFF)
HARDWARE FLOW CONTROL	CTS (clear to send signal)




- 2 RXD
- 3 TXD
- 4 CTS
- 5 RTS*
- 7 GND

*RTS is always a "space"
(+5 to +10VDC)

Memory DATA output thru RS232C

Data can be transferred from the memory in all three modes. Press RECALL to display memory DATA and then press MEMO SET



ON-DEMAND STATISTICS	CONTINUOUS STATISTICS	STANDARD Units lbs Max 98.8
Units lb	Units lb	Max - 0.0
DATA 100	DATA 100	MIN
MAX	MAX	MIN
MIN	MIN	LAST
AVG.	PKC	**END**
DEV	PKT	
HLMT	AVG	
LLMT	DEV	
	HLMT	
	LLMT	

DATA

1 XXXX	
2 XXXX	DATA
3 XXXX	1 XXXX
	2 XXXX

RS232C

Output DATA format from gauge

1	2	3	4	5	6	7	8	9	10	11	12	13	
CR	S	T	A	T	I	S	T	I	C	S	CR	LF	
U	N	I	T	S					g	f	CR	LF	
D	A	T	A					1	0	0	CR	LF	
M	A	X		-				1	0	0	CR	LF	
M	I	N		-					1	0	CR	LF	
P	K	C								0	CR	LF	
P	K	T		-			1	1	0	0	CR	LF	
A	V	G		-				9	1	2	CR	LF	
D	E	V						8	.	2	CR	LF	
H	L	M	T		-			1	0	0	CR	LF	
L	L	M	T		-				9	0	CR	LF	
CR	LF												
	D	A	T	A	-				9	1	5	CR	LF
		1											
		2		L	-				8	9	5	CR	LF
	9	9		H	-			1	0	0	5	CR	LF
1	0	0							9	9	0	CR	LF
	*	*		E	N	D		*	*				

External control command

ASCII Capital Characters

COMMAND	FUNCTION	DATA
UNTG	Change units to g or kg	
UNTN	Change units to N	
UNTL	Change units to lb or oz	
DSPN	Change mode to average	
DSPT	Change mode to peak tension	
DSPC	Change mode to peak compression	
PKCL	Peak clear reset	
MEMS	Display value stored in memory	
CPST	Upper and lower limit set	+dddd+dddd
MEMC	Last data in memory clear	
MEMD	Memory data output	
MEMZ	Clear all data in memory	
MEMN	Memory location recall	
Z	Tare	
UPD	Display update	1, 2, 3, 4
APF	Auto - power - off	0, 3
EXS	External input setting	Z, H, N
HLD	Hold trigger mode	E, L O, C
LOG	Memory mode setting	S, C, N
PKF	Peak fast mode	0, 1
D	Output displayed data	
DATN	Output average mode data	
DATT	Output tension peak data	
DATC	Output compression peak data	
LIST	Gauge's present state	

RS232C

External control command

ASCII Capital Characters

- **UNTG, UNTN, UNTL** - Change UNITS to Kg, N, lb
 UNTG CR... Kg(g)
 UNTN CR... N
 UNTL CR... lb (oz)

- **DSPN, DSPT, DSPC** - Change to average, peak tension, peak compression mode.

DSPN CR... Change to average mode
 DSPT CR... Change to peak tension mode
 DSPC CR... Change to peak compression

- **PKCL** _____ Peak Clear

PKCL CR.... Peak reset. Same as reset from the gauge. If edge trigger is selected for HOLD, the PC can release the HOLD using this particular command.

- **MEMS, MEMC, MEMD, MEMZ, MEMN**
 (five control memory commands).

MEMS CR.... with this command if gauge is set in the ON-DEMAND (single) mode, it sends back to the computer the word SING. If gauge is set in the continuous or standard mode then when this command is sent and the gauge's memory starts, it sends back to PC the word STA. If memory stops, the word STP is sent back to the PC.

MEMC CR.... Last DATA in memory to clear
 MEMD CRMemory DATA recall
 MEMZ CR ... Clear all DATA in memory
 MEMN CRMemory location recall

- **CPST** _____ Comparator Setting

CPST 0 0000 0 0000 CR
SIGN UPPER SIGN LOWER
 LIMIT LIMIT

Example: CPST 1234-0123 CR
SPACE need 4-digit # (fill with zeros)

- **Z** _____ TARE

Z CR To TARE. Works the same way as if it were done thru the gauge i.e SHIFT + ZERO.

- **UPD** _____ Display Update Time

UPD CR, = 1: 0.125 sec.
 2: 0.25 sec.
 3: 1 sec.
 4: 2 sec.

- **APF** _____ Auto-Power-Off
 APF CR, = 0: none
 3: 3 minutes

- **EXS** _____ External Input Setting
 EXS CR = Z: TARE
 H: HOLD
 N: NONE

- **HLD** _____ HOLD Trigger Mode
 HLD CR = E: Edge
 L: Level
 O: Open Contact
 C: Closed Contact

- **LoG** _____ Memory Mode Setting
 LoG CR = S: Single
 = C: Continuous
 = N: Standard

- **PKF** _____ PEAK Fast Mode
 PKF CR = 0: OFF
 = 1: ON

- **D, DATN, DATT, DATC** _____ Data output request (4 commands)

D CR Output displayed DATA
 DATN CR Output average mode DATA
 DATT CR Output tension PEAK DATA
 DATC CR Output compression PEAK DATA

- **LIST** _____ Gauge's present state

LIST	CR (Command from PC)								
MDL	DFS-0.5	-	-	-	-	-	-	-	Typical gauge response
Units	g								
DSPM	Normal								
DSPT	0.125 sec								
PKFST	ON								
OFFT	3 min								
232C	4800 B8 S2								
232C	PN CR LF X OFF								
CP	ON								
HLMT	200.0								
LLMT	100.0								
ET	HOLD								
ET	LEVEL CLOSE								
LOG	NONE	-	-	-	-	-	-	-	

■ Gauge Response

OK Command accepted
 ERRO Did not recognize command*
 ERR1 Command cannot be processed*
 ERR2 Wrong nomenclature, i.e N,S,C*
 ERR3 Communications error*
 IN HOLD ... When in HOLD, certain commands cannot be processed.
 IN MEMORY.. When in continuous memory mode or standard mode (active), certain commands can be processed.

*Check command and resend

UNITS CHANGE DISABLE This output is transmitted to PC when someone is trying to change UNITS while memory is accepting DATA.

■ Flow Control

Flow control can be accomplished by CTS input and software.

1. Control by CTS



When CTS is a "space" (5 ~ 10VDC), communications are enabled. When CTS is a "mark" (-5 ~ -10VDC), communications are disabled.

2. Software flow control

If software flow control is selected, communications flow control can be accomplished thru RS232C by sending XON or XOFF. XON (enable: ASCII position $D_1 \rightarrow H11$). XOFF (disable: ASCII position $D_3 \rightarrow H13$). If "disabled" is over 5 seconds, Er06 is displayed momentarily, unit defaults to measure mode and communications stop.

■ Over-load output

When load exceeds approximately 120% of gauge's capacity an open collector transistor turns ON (there are two OC NPN transistors, one for tension and one for compression). The output of these transistors can be used as an alarm or to stop a process, thus protecting the gauge or the sample (material) under test.



Both transistors can handle up to 28VDC, 5 mA.

■ Statistics

Statistics for up to 100 measurements can be performed using the following formulas:

$$(DATA) = n, (AVE) \bar{x} = \sum \bar{x}_i / n, (DEV) s = \sqrt{\sum (x_i - \bar{x})^2 / n}$$

Note: For above calculations only absolute values are used even though algebraic signs may appear on the display.

Calibration

The DFS series is an easy series to calibrate. At the same time certain caution should be exercised not to lose the calibration data in the process.

■ Before proceeding with calibration


- Secure a stand or some kind of fixture.
- Secure calibration weight
- Calibration weight has to be precise, full scale and in Kg/g only.
- Avoid vibration totally.

Note: If the analog output is used, steps 1 thru 15 must be used. If the analog output is not used, steps 1 thru 11 must be used. When steps 1 thru 11 are used, the analog zero maybe slightly off.



Calibration Procedure

- Turn power off. Use hook attachment and mount unit on a stand or fixture up-side-down.
- Press MEMO SET first and hold, then press ON and hold for approximately 4 seconds till display shows CAL.
- Press MEMO SET. Display will go to hex data. Wait approximately 10 minutes for the unit to warm up.
- Zero position calibration

Press MEMO SET with no load. Down arrow will blink and after 6 seconds it will go on solid and display will show a hexadecimal number between 7E0 and 8C0 which has no particular meaning to the operator.



- Hang calibration weight. Press MEMO SET. Upper arrow will blink and after 6 seconds it will go on solid. The display will show a hexadecimal number depending on the particular model under calibration. This number has no meaning to the operator.



- Now SPAN calibration is complete. Turn power off.
- Take unit out from stand or fixture and place it in a horizontal position.
- Press MEMO SET first and hold, then press ON and hold for approximately 4 seconds. The display will show CAL.
- Press MEMO SET and wait approximately 30 seconds.
- Press MEMO SET again. Arrow will blink and then go solid.
- Calibration is now complete. Turn power off. **DO NOT** press MEMO SET before turning power off, otherwise you will have to start with step 2 again.
- Keep unit in horizontal position and press RECALL and ON simultaneously and hold for approximately 4 seconds till display shows .
- Press MEMO SET. The unit will display along with a hexadecimal number depending on the output residual analog voltage.
- Measure analog output voltage and adjust to zero using the ▲ and ► switches. If ► switch is pressed, the output voltage increases. If the ▲ switch is pressed, the output voltage decreases.
- Press MEMO SET and then turn power off.

Note: After step 12, be careful not to touch the ON key. If the ON key is touched accidentally, the display will go to some hexadecimal number. To default press ON key twice. The display will show the number as in step 13 above. See diagram below.

SHIMPO ONE-YEAR WARRANTY

LIMITED EXPRESS WARRANTY: Shimpo Instruments warrants, to the original purchaser of new products only, that this product shall be free from defects in workmanship and materials under normal use and proper maintenance for one year from the date of original purchase. This warranty shall not be effective if the product has been subject to overload, misuse, negligence, or accident, or if the product has been repaired or altered outside of Shimpo Instruments's authorized control in any respect which in Shimpo Instruments's judgment, adversely affects its condition or operation.

DISCLAIMER OF ALL OTHER WARRANTIES: The foregoing warranty constitutes the SOLE AND EXCLUSIVE WARRANTY, and Shimpo Instruments hereby disclaims all other warranties, expressed, statutory or implied, applicable to the product, including, but not limited to all implied warranties of merchantability and fitness.

LIMITATION OF REMEDY: Under this warranty, Shimpo Instruments's SOLE OBLIGATION SHALL BE TO REPAIR OR REPLACE the defective product or part, at Shimpo Instruments's option. Shimpo Instruments reserves the right to satisfy warranty obligation in full by reimbursing Buyer for all payments made to Shimpo Instruments,

whereupon, title shall pass to Shimpo Instruments upon acceptance of return goods. To obtain warranty service, Purchaser must obtain Shimpo Instruments's authorization before returning the product, properly repackaged, freight pre-paid to Shimpo Instruments.

INDEMNIFICATION & LIMITATION OF DAMAGES: Buyer agrees to indemnify and hold Shimpo Instruments harmless from and against all claims and damages imposed upon or incurred arising, directly or indirectly, from Buyer's failure to perform or satisfy any of the terms described herein. In no event shall Shimpo Instruments be liable for injuries of any nature involving the product, including incidental or consequential damages to person or property, any economic loss or loss of use.

MERGER CLAUSE: Any statements made by the Seller's representative do not constitute warranties except to the extent that they also appear in writing. This writing constitutes the entire and final expression of the parties' agreement.

Specifications

MODELS	DFS-0.5 DFS-0.5R	DFS-1 DFS-1R	DFS-2 DFS-2R	DFS-5 DFS-5R	DFS-10 DFS-10R
CAPACITY	8 oz 200 g 2 N	16 oz 500 g 5 N	2 lb 1000 g 10 N	5 lb 2 Kg 20 N	10 lb 5 Kg 50 N
RESOLUTION	0.01 oz		0.001 lb		
	0.1 g		1 g	0.001 Kg	
	0.001 N		0.01 N		
ACCURACY	±0.2% FS + 1/2 digit at 23°C				
DISPLAY	4-Digit LCD, 11.5 mm High with various indicators including Low Battery I				
MEASURING MODE	Average, Peak Compression, Peak Tension (selectable)				
DISPLAY UPDATE	125 ms, 250 ms, 1 sec, 2 sec (selectable)				
SAMPLING RATE	Average Mode: 125 ms, 250 ms, 1 sec, 2 sec Peak Mode: 1 ms, 125				
TEMPERATURE COEFFICIENT	Zero: ±0.02% FS/°C (max.), Span: ±0.015% of reading/°C (max.)				
OUTPUTS	1. RS232C 2. Digimatic: (works with Mitutoyo's printer model DP-1HS 3. Analog: (±1VDC with load impedance of 2K or higher and tare function)				
OVERLOAD CAPACITY	200% of FS				
COMPARATOR OUTPUT (Set Points)	Three open collector NPN transistors for HI, GO, and LO (28VDC, 7 ma rr				
OVERLOAD OUTPUT	Two open collector NPN transistors one for Tension and one for Compre:				
TARE & HOLD CONTROL	Relay contact (selectable)				
MEMORY	Holds 100 samples plus statistics (MAX, MIN, AVG, and Standard Deviat				
POWER	4 - AA Alkaline batteries. Last approx. 20hrs. in continuous operation or A				
AUTO POWER SHUT-OFF	Selectable (3 minutes if there is no activity)				
OPERATING TEMP RANGE	32 - 113°F (0 - 45°C)				
DIMENSIONS/WEIGHT	3"W x 1.77"H x 9.72"L (76 x 45 x 247)mm /1.2 lbs. (550 g)				
ACCESSORIES (Included)	Batteries, carrying case, overload output cable, AC adapter, 6 adapters (f extension rod)				
ACCESSORIES (Available)	Test stands, RS232C cable, Digimatic, analog and comparator output cal				

